

The **SETUP** KEY is used for all programming sequences (e.g. Device Setup)

Press **CBL, TV, VCR DVD or AUD** to select which device you want to control

Press **GUIDE** to display all the programs available to view.

Press **SETTINGS** to access your cable converter options.

Press the **Cursor keys** to move the cursor in the program guide and menu screens.

Reserved as Macro Keys to be programmed to address premium channels or interactive services.

Press the **REW, LIST, and LIVE** keys to perform the following functions:

REW -Replays the previous few seconds of a program

LIST- Displays a list of programs that have been recorded.

LIVE- Displays Live TV programming

Press **PIP ON/OFF** to open close the PIP window.

Press **SWAP** to swap the content being viewed in the PIP window with the program being view on the main screen

Press **Video Source** to change inputs..

Press the **POWER** key to turn ON/OFF the selected device. This key is also programmable to turn ON/OFF all of your devices with a single key press.

Press **MENU** to access various program options.

Press **INFO** to display additional information about the program you selected.

Press **SELECT** to Choose options from the MENU or Programs from the GUIDE.

Use the **PAGE UP/DOWN** keys to page up or down while in the GUIDE.

Press **EXIT** return to watching a program when exploring the GUIDE or MENU.

Press **A B and C** keys to access addiitonal options while viewing the Guide or Menu

Press **FAV**, to cycle through the Favorite channels you have stored in the cable converter.

Press **LAST** to return to the last channel or page back one page in the menu or guide.

Press **REW, PLAY, FFWD, RECORD, STOP and PAUSE** keys to control the DVR or selected VOD event

Also used to control the VCR or DVD.

Press **MOVE** to change the location of the PIP window when active.

Press **CH +/-** to change the channels in the PIP window..

